

AURELIA® 103

White Nylon Glove with Blue PVC Dots

S/7	M/8	L/9	XL/10
103-7	103-8	103-9	103-10

Instructions for use, in accordance with Regulation EU 2016/425 on PPE

WARNING

Performance levels relate to the palm of the glove only. The levels of performance are only valid for new gloves, not washed or regenerated. These levels of performance are obtained from the tests done according to conditions defined by the applicable standards. For gloves with different layers of material, the performance levels are warranted only for the whole glove. For gloves with two or more layers the overall classification does not necessarily reflect the performance of the outermost layer.

No protection offered against liquids or chemicals. Do not use these gloves to protect against serrated edges or blades or naked flames. These gloves shall not be worn when there is a risk of entanglement by moving parts or machines. This glove shall not be in contact with fire.

Always confirm that products are in conformance with standards, tested and to the level that is in accordance with your requirements. This model does not contain any substances at levels that are known to or suspected to, adversely affect user hygiene or health.

Before use, always check the glove for any sign of deterioration. The glove should be scrapped in the event of any visible signs of deterioration, including, but not limited to abrasion, tears, cuts.

DESCRIPTION OF USE

Protective gloves against mechanical risks.

Donning (Putting on): Wash and dry your hands completely before use. Always inspect the gloves internally and externally for any defects or imperfections. Ensure the gloves fit well.


Doffing (Removing): Avoid touching contaminated or cold gloves. Place the fingertips into the palm of the other glove. Pull the glove until almost off. Repeat on the other hand. With both gloves almost off shake both hands to remove the gloves fully.

CARE INSTRUCTIONS

Storage and Cleaning:

After use, clean the gloves thoroughly with a dry cloth to remove any contaminants. If the gloves are to be re-worn store in such a way that the inside lining can dry out easily. These gloves cannot be washed.

Store the gloves in their original packaging in a cool and dry place. Keep away from direct sunlight, heat, flame and sources of Ozone. Glove life time is not significantly affected by aging under normal conditions of temperature and humidity and user should replace when worn out (looking at abrasion, cuts and tears).




AURELIA® 103

White Nylon Glove with Blue PVC Dots

DISPOSAL INSTRUCTIONS

At the end of life, used gloves may be contaminated with hazardous substances, dispose of according to the Local Authority Regulations, landfill or incinerate under controlled conditions.

Product is in conformity with Regulation EU 2016/425 on PPE, Category II Dexterity Level 5			
Testing requirement	Description	Test Result	Explanation of test and Level
EN ISO 21420:2020	General Requirements	Pass	Risk Category, Labelling
EN388:2016 +A1:2018  214XX	Mechanical Hazards	2	Abrasion Resistance: Level 0-4
		1	Coupe Test, Blade Cut Resistance: Level 0-5
		4	Tear Resistance: Level 0-4
		X	Puncture Resistance: Level 0-4
		X	TDM Cut Resistance, ISO 13997: Level A-F 'X' Not Tested



CE certificate issued by:
 CTC Notified Body No. 0075, 4, rue Hermann Frenkel 69367 Lyon Cedex 07 France

Declarations of Conformity available at:
www.aureliagloves.co.uk | www.aureliagloves.ie



Manufactured in China on behalf of:
UK & Europe HQ
 Supermax Healthcare Limited
 Units 12-16 Titan Drive,
 Fengate, Peterborough,
 PE1 5XN


+441733 615215
sales@supermax.co.uk
www.aureliagloves.co.uk



Europe
 Supermax Healthcare (Europe Limited)
 Units 1001-1012
 Building 1000, Gateway Business Park,
 New Mallow Road Cork, Ireland

+353 15256724
sales@supermax.ie
www.aureliagloves.ie




 @aureliaglovesuk